

# HYDRWING

## Manual HydroWing Operating, Maintenance & Warranty Instructions

**WARRANTY** *(Please also refer to our detailed terms and conditions of sale)*

1 year warranty on all parts for fair wear and tear. *(For warranty please call 01945 461741)*

Return faulty part to Dawbarn and Sons for inspection and warranty claim *(a replacement will be sent within 24 hours)*

ALL PARTS WILL BE SUPPLIED FOC IF THEY HAVE FAILED UNDER WARRANTY PERIOD WITH FAIR WEAR AND TEAR.

Do not attempt to repair or take apart the gearboxes as this may invalidate your warranty.

PARTS MUST ONLY BE REPLACED WITH ITEMS SOLD AND APPROVED BY DAWBARN AND SONS LTD

If you have any questions please call 01945 461741

- **TO OPEN NETS** Release offside winding handle from the mounting bracket and wind the net until in the fully open position against the offside of the trailer.  
Release nearside winding handle from the mounting bracket and wind the net until in the fully open position against the nearside of the trailer.
- **TO CLOSE NETS** Using the nearside winding handle wind the net until in the fully closed position on top of the trailer. Lock the winding handle into place on the mounting bracket  
Using the offside winding handle wind the net until in the fully closed position on top of the trailer. Lock the winding handle into place on the mounting bracket.

### IMPORTANT

- DO NOT travel with the nets in the open position
- ALWAYS OPEN NETS BEFORE TIPPING THE LOAD
- DO NOT OPEN OR CLOSE NETS IN HIGH WINDS
- CHECK FOR POWER CABLES ABOVE THE TRAILER BEFORE OPENING / CLOSING THE NETS

### MAINTAINANCE

Inspect nets daily

Lubricate the hinges when required, using the grease nipples

